

# INSTRUCTION MANUAL MANUEL D'INSTRUCTIONS



## F-375 CONSTRUCTION HEATER CHAUFFAGE DE CONSTRUCTION F-375

### SPECIFICATIONS:

SPECIFICATIONS:	
Model	F-375
Fuel	Vapor propane
Input (maximum)	375,000 btu/h
(minimum)	220,000 btu/h
Manifold pressure	7 to 20 psig
Hose length	20-ft standard
Regulator with POL	Preset at 20 psig max
Approved	ULC listed
Weight	60 lbs
Dimensions	42" x 17 1/4" x 22"
Air Outlet	13" diameter
Fuel Consumption	10.1 – 17.3 lbs per hour
Ignition	Manual

SPECIFICATIONS :	
Modèle	F-375
Combustible	Propane de vapeur
Contribution (maximum)	375,000 btu/h
(minimum)	220,000 btu/h
Pression multiple	7 à 20 psig
Longueur de tuyau	20 pd norme
Régulateur avec POL	Programmé à 20 psig max
Approuvé	ULC Énuméré
Poids	60 livres
Dimensions	42" x 17 1/4" x 22"
Issue aérienne	13" diamètre
Consommation du Combustible	10.1 à 17.3 livres par heure
Ignition	Manuel

Clearance to combustibles:			Déblayage aux combustibles :		
ABOVE	IN FRONT	SIDE	EN HAUT	EN AVANT	A COTE
7-feet	10-feet	2-feet	7-pied	10-pied	2-pied

## **CAUTION:**

- ◆ *Pipe Fittings:* When loosened, tightened or replaced, the complete fittings should be removed and approved pipe dope applied to the male threads.
- ◆ *Flare Fittings:* No pipe dope is required on the SAE flare fittings.
- ◆ *Leaks:* When a heater is serviced, the valve train should be checked for leaks with a soap and water solution or approved leak detector solution.
- ◆ *Installation & Maintenance:* Heaters are to be installed and operated in accordance with CGA Standard B149.1-00 Installation Code and to any provincial or local code. Service should be carried out only by qualified propane gas fitters.
- ◆ *Fan Assembly:* Ensure heater is fired only on a level surface. When the fan assembly is mounted but not running, the motor can be damaged if the gas pressure is low and the heater is tilted forward.
- ◆ Do not store or use gasoline, flammable vapour of flammable liquids in the vicinity of the heater.

## **Burner Fails to Ignite:**

- ◆ Ensure the cylinder valve is opened slowly. Check the cylinder has propane inside by the weight of the cylinder, or by slowly disconnecting the cylinder and checking for high pressure from the cylinder valve outlet.
- ◆ Check that the regulator is screwed in fully (clockwise).
- ◆ Depress the reset button fully and light the burner.
- ◆ Refer to the valve train drawing and disconnect the copper line from the low fire orifice. Depress the reset button and gas should pass through the line. If the flow is not evident, or minimal, there could be a blockage in: (a) *POL with excess flow check* (b) *Regulator* (c) *Hose* (d) *Strainer* (e) *Safety valve*.
- ◆ When the low fire line is disconnected, remove the low fire orifice and clean with a #72 DMS drill.
- ◆ The pilot burner should ignite unless there is a blockage in the main orifice. The main orifice should then be removed and cleaned with a #43 DMS drill.

## **Main Burner Fails to Fire Correctly:**

- ◆ Depress the reset button and light the pilot burner, keep the reset button depressed for 45 seconds. When released, the low fire should alternate to high fire. If this fails to burn at full fire or burns with a yellow flame, remove the main orifice and clean with a #43 drill.
- ◆ If you have the optional igniter on your heater, depress the igniter button and turn to generate spark for the pilot burner. Keep the button depressed for 45 sec. When released, the burner should alternate to high fire. If it fails to burn at full fire, or burns with a yellow flame, remove the main orifice and clean with a #43 DMS drill.
- ◆ Reset button could be binding and not releasing correctly. In this case the safety valve should be replaced.

## **Burner Fails to Remain Lit:**

- ◆ Replace the thermocouple
- ◆ Replace the safety valve

## **ATTENTION:**

- ◆ *Essayages de Pipe : Quand desserré, serré ou remplacé, les essayages complets devraient être enlevés et la dope de pipe approuvée s'est appliquée aux filetages mâles.*
- ◆ *Fuites : Quand un chauffage est assuré l'entretien, le train de valve devrait être vérifié pour les fuites avec une solution d'eau et savon ou a la solution de détecteur de fuite approuvé.*
- ◆ *Installation et Maintenance : les chauffages doivent être installés et faits marcher conformément au Code d'Installation de B149.1-00 Standard CGA et à n'importe quel code de province ou local. Le service devrait se faire seulement par les monteurs de gaz de propane qualifiés.*
- ◆ Le chauffage devrait seulement être renvoyé sur une surface de niveau.
- ◆ Ne conservez pas ou utilisez de l'essence, la vapeur inflammable de liquides inflammables aux alentours du chauffage.

## **Le Brûleur Manque de S'enflammer:**


- ◆ Garantisiez que la valve de cylindre est ouverte lentement. Vérifiez le cylindre a du propane à l'intérieur par le poids du cylindre, ou en en débranchant lentement le cylindre et en vérifiant pour la haute pression de l'issue de valve de cylindre.
- ◆ Vérifiez-le le régulateur est vissé dans complètement (dans le sens des aiguilles d'une montre).
- ◆ Déprimez le bouton de réinitialisation complètement et allumez le brûleur.
- ◆ Faites allusion au dessin de train de valve et débranchez la ligne cuivre de l'orifice de feu bas. Déprimez le bouton de réinitialisation et le gaz devrait traverser la ligne. Si l'écoulement n'est pas évident, ou minimal, il pourrait y avoir un blocage dans : (a) POL avec chèque l'excès coule (b) le Régulateur (c) le Tuyau (d) la Passoire (e) la Soupape de sûreté.
- ◆ Quand la ligne de feu basse est débranchée, enlever l'orifice de feu bas et propre avec un #72 foreuse de DMS.
- ◆ Le brûleur pilote devrait s'enflammer à moins qu'il n'y ait un blocage dans l'orifice principal. L'orifice principal devrait alors être enlevé et nettoyé avec une #43 foreuse de DMS.

## **Le Brûleur Principal Manque de Tirer Correctement :**

- ◆ Déprimez le bouton de réinitialisation et allumez le brûleur pilote, conservez-vous le bouton de réinitialisation a déprimé depuis 45 secondes. Quand libéré, le feu bas devrait se relayer pour haut tirer. Si cela manque de brûler au feu complet ou brûle avec une flamme jaune, enlevé l'orifice principal et propre avec une #43 foreuse de DMS.
- ◆ Si vous avez l'allumage électronique optionnel sur votre chauffage, déprimez le bouton d'allumage électronique et tourne le produire l'étincelle pour le brûleur pilote. Conservez-vous le bouton a déprimé pour 45 sec. Quand libéré, le brûleur devrait se relayer pour haut tirer. S'il manque de brûler à un feu complet, ou brûle avec une flamme jaune, enlevé l'orifice principal et propre avec une #54 foreuse de DMS.
- ◆ Le bouton de réinitialisation pourrait attacher et ne pas libérer correctement. Dans ce cas-là la soupape de sûreté devrait être remplacée.

## **Le Brûleur Manque de Rester Allumé :**

- ◆ Remplacez le thermocouple
- ◆ Remplacez la soupape de sûreté



#### PARTS LIST

#### NO.

#### LIST DES PIECES

POL with excess flow check  
Regulator  
20 ft Hose Assembly  
1/4" Forged Street Elbow  
1/4" Gas Strainer  
G08 Low Fire Orifice  
Thermocouple  
1/4" Street Elbow  
1/4" Tee  
Main Orifice  
Burner Head  
Burner Mount Clamp  
Heater Body  
1/4" Steel Coupling  
Safety Valve (Brass Body)  
1/8" Pipe x 1/4" Flare Elbow  
Low Fire Line c/w Flare Nuts  
1/4" Pipe x 1/4" Flare Elbow

S-01	Détendeur avec clapet de retenue
S-02	Régulateur
S-03	Ensemble de tuyau 20 pd
S-04	1/4 Coude de rue
S-05	1/4 " Passoire
S-11	Orifice de feu bas G08
S-12	Thermocouple
S-13	1/4 " Coude
S-14	1/4 " Tee
S-24	Orifice principal
S-25	Tête de brûleur
S-26	mont de brûleur
S-27	Corps de chauffage
S-53	Coupling D'acier 1/4 "
S-34	Soupape de sûreté (corps en laiton)
S-38	Tuyau 1/8" x coude 1/4 "
S-39	Ligne de feu bas avec les noix
S-40	Tuyau 1/4 " x coude 1/4 "

#### B-375 FAN PARTS

#### PIECES DU VENTILATEUR B-375

Fan Motor  
Fan Blade  
Motor Mount Clamp  
Fan Housing

S-29	Moteur du ventilateur
S-30	Ailette du ventilateur
S-31	Attache de mont de moteur
S-32	Enveloppe du ventilateur

**FLAGRO INDUSTRIES LIMITED**  
26 Benfield Drive  
St. Catharines, Ontario  
Canada L2S 3V5


**Telephone: 905-685-4243**  
**Fax: 905-685-0113**  
**E-mail: flagro@flagro.on.ca**  
**Website: www.flagro.on.ca**

---

## *F-375 CONSTRUCTION HEATER*

### *PARTS LIST*





**flagro**  
INDUSTRIES LIMITED



# F-375 CONSTRUCTION HEATER

## PARTS LIST

**flagro**  
INDUSTRIES LIMITED



# **F-375 CONSTRUCTION HEATER**

## **PARTS LIST**



### **ACCESSORIES**



## **PARTS LIST**

Item #	Description	P/N
1	POL WITH EXCESS FLOW CHECK	S-01
2	HIGH PRESSURE REG.	S-02
3	20FT HOSE ASSEMBLY	S-03
4	1/4" Brass Street Elbow	S-04
5	1/4" gas strainer - 1/4" MNPT x 1/4" FNPT	S-05
6	1/4" coupling	S-33
7	Safety Valve	S-34
8	1/4" Steel Nipple	S-41
9	1/4" B.M. Street Elbow	S-13
10	1/8" FP x 1/4" MF connector	S-38
11	Low Fire Line c/w flare nuts	S-39
12	1/4" MP x 1/4" MF orifice holder	S-40
13	Low Fire Line	S-11
14	1/4" B.M. tee	S-14
15	Main Orifice	S-24
16	Burner Head	S-25
17	Thermocouple	S-12
18	Two Cylinder Manifold	2001-S2
19	Three Cylinder Manifold	2001-S3
20	Air Mover (optional)	B-375

**flagro**  
INDUSTRIES LIMITED



# **PARTS LIST FOR F-150 & F-375**

<b>Part Number</b>	<b>Part Description</b>	
S-01	POL WITH EXCESS FLOW CHECK	
S-02	HIGH PRESSURE REGULATOR	
S-03	1/4ID MNPT X MNPT 20-FT HOSE ASSEMBLY	
S-04	1/4" BRASS STREET ELBOW	
S-05	1/4" GAS STRAINER - 1/4" MNPT X 1/4" FNPT	
S-06	BASO SAFETY VALVE (ALUMINUM BODY)	
S-07	1/4" STEEL NIPPLE	
S-11	LOW FIRE ORIFICE	
S-12	THERMOCOUPLE 18"	
S-13	1/4" B.M. STREET ELBOW	
S-14	1/4" B.M. TEE	
S-24	MAIN ORIFICE FOR F-375	
S-25	BURNER HEAD FOR F-375	
S-26	BURNER MOUNT CLAMP FOR F-375	
S-29	FAN MOTOR FOR B-375 FAN ASSEMBLY	
S-30	FAN BLADE FOR B-375 FAN ASSEMBLY	
S-31	MOTOR MOUNT CLAMP FOR B-375	
S-33	1/4" COUPLING (STEEL OR BRASS)	
S-34	SAFETY VALVE (BRASS BODY)	
S-38	1/8" FP C 1/4" MF CONNECTOR	
S-39	LOW FIRE LINE C/W FLARE NUTS FOR F-375	
S-40	1/4" MP X 1/4" MF ORIFICE HOLDER	
S-41	1/4" STEEL NIPPLE	
S-42	MAIN ORIFICE FOR F-150	
S-43	1/4" GAS STRAINER - ELBOW	
S-44	1/4" MP X 1/4" FB ADAPTER	
S-45	1/4" MP X MF ELBOW-ORIFICE HOLDER	
S-46	1/4" MF X 1/8" FB ELBOW	
S-47	LOW FIRE LINE C/W FLARE NUTS FOR F-150	
S-50	SHIELD FOR F-150	
S-51	BURNER MOUNT PLATE FOR F-150	
S-54	BURNER HEAD FOR F-150	
S-64	HOSE ASSEMBLY SAFETY CLIP	